

Rules for unloading of metallurgical materials

Rules for metallurgical material deliveries are for suppliers obligatory.

Agrostroj reserves the right to refuse partly or fully the delivery of metallurgical material in case of their nonobservance.

Storehouse working hours:

Р	elhřimov	06:00-22:00	Χ	Humpolec	06:00-14:00	Χ	Počátky	06:00-14:00	
---	----------	-------------	---	----------	-------------	---	---------	-------------	--

Notice: It's imperative to bring the delivery car at least 1 hour before the end of the storehouse working hours.

Every delivery determined for the storehouse in Pelhřimov must be reported at least one working day before in order to assign an unloading order for one of the contacts below:

Mrs. Buchtová phone: +420 565 360 157 Email : lvana.Buchtova@agrostroj.cz

Notice.: In case of being unavailable use another reserve contact:

Mr. Janko mobile: + 420 725 094 688 Email: Rostislav.Janko@agrostroj.cz

Mr. Pejchl mobile: + 420 734 164 989 Email: <u>Jaroslav.Pejchl@agrostroj.cz</u>

- 1. Metallurgical material attests must be sent by e-mail to the address: atesty@agrostroj.cz and this must be done at least 1 day before the planned unloading in Agrostroj.
- 2. The delivery note and the attests must be at the moment of delivery at disposal. Without them the material will not be accepted. It must include the order number and the numbers of Agrostroj items.
- 3. Each bundle must be labelled with a label on which it is quoted:
 - a. Order number,
 - b. Item number,
 - c. Material quality,
 - d. Material quantity.
- 4. The bar steel must be marked with colour according to quality (by works standards AVN 00 0066).
- 5. It is unconditionally necessary to keep the maximum stated size of the bundle. The height of metal sheet is maximum 80 mm.
- 6. The unloading of bar material can be done only with the crane.
- 7. We require using of material piling strips by metal sheet deliveries in the minimal dimensions 80 x 80 mm.
- 8. The metallurgical material must be transported exclusively by covered trucks in order to be unloaded. Wet, rusty or otherwise devaluated deliveries will not be unloaded in Agrostroj.